


Instructions de mise en œuvre



type SLD




type ✓

R120/
R0 ✓

type SLD-Q




1




2A

2B



2C

2D



3

type SLD part S



type ✓


○ ✓

type SLD-Q part S




type ✓


□ ✓




4



5




6




7A

7B



8




9


SLD

Conception de la structure


Instructions de mise en œuvre









type SLD part A4



type SLD-Q part A4



part BSM



SLD

Conception de la structure