



Schöck Isokorb® XT type C













XT
type C

Reinforced concrete – reinforced
concrete

Installation instructions – connection across the corner




Installation instructions – connection across the corner











XT
type C

Reinforced concrete – reinforced
concrete

Installation instructions – linear connection



Installation instructions – linear connection



XT
type C

Reinforced concrete – reinforced
concrete