

Schöck Isokorb® T type S




T
type S


Steel – steel


Installation instructions







type S-N




type S-V






 Check all screw threads for ease of movement. If necessary, clean and lubricate first!



type	Screw threads	Width across flats
S-N-D16	M16	24 mm
S-N-D22	M22	32 mm
S-V-D16	M16	24 mm
S-V-D22	M22	32 mm



Installation instructions



type	Screw threads	Width across flats
S-N-D16	M16	24 mm
S-N-D22	M22	32 mm
S-V-D16	M16	24 mm
S-V-D22	M22	32 mm

